




MADE BY ZEN[®]



ESTA

Bamboo Aroma Diffuser

Create a sense of inner balance and
calm with a cool scented mist

TABLE OF CONTENTS

A. ABOUT THE ESTA

B. SPECIFICATION

C. OPERATING PROCEDURE

D. MAINTENANCE

E. TROUBLESHOOTING

F. WARRANTY

**Congratulations on purchasing the
MADE BY ZEN® Esta Aroma Diffuser.
Please keep this manual for further
reference and maintenance.**



ABOUT THE ESTA

Imagine inhaling the purifying air of a bamboo forest, as the wind brushes through the leaves carrying its natural scents towards you. The Esta Bamboo Aroma Diffuser is the ideal way to rejuvenate your home with fragrance and light to magically transform your surroundings by bringing the beauty of nature indoors.

The Esta Aroma Diffuser is stylishly designed using bamboo from a sustainable source. The bamboo is selected and cut by hand, allowing maturing and flowering strands to remain flourishing and have the least impact on wildlife.

Caring for our planet is important to us and we are committed to the protection and conservation of the earth as much as possible.

By combining natural materials, highly skilled craftsmanship, and aromatherapy, the Esta Aroma Diffuser will enhance any living space and help reduce stress.

Modern, ultrasonic technology is used to diffuse tap water and fragrance or essential oils into the air, in a plume of fine mist and fragrance, calming the mind, body and soul.



LED Bulbs

Warm, ambient LED lighting with a variety of settings which help you to relax.

- Choice of two intensity settings
- Soft glow, fixed ambient light
- Sleep mode (no light) option



Aromatherapy

Suitable for use with any essential or fragrance oils (madebyzen® oils recommended).




Intermittent Mist Setting

The Esta Aroma Diffuser also has an intermittent mist setting, which automatically controls the scent diffusion, by intermittently switching the mist on and off every 30 seconds. This is ideal for using stronger scents/oils, or when scent is desired for a longer period of time.




SPECIFICATION

Model Name: Esta
Model No: EW030
Product Size: $\Phi 91 \times 157 \text{mm}$
Power: 12W
Voltage: DC 12V
Water Capacity: 100ml
Run Time: Approx 4 hours



- 01. Mist Outlet
- 02. Cover
- 03. Max. Water Level Line
- 04. Ceramic Disc
- 05. Bamboo Shell
- 06. Water Tank
- 07. Vent Hole
- 08. Mist Button
- 09. Light Button
- 10. Adaptor
- 11. DC Jack



IMPORTANT NOTES BEFORE USE:

1. Place the aroma diffuser on a flat surface, at least 60cm away from the floor and at least 10cm away from the wall. **DO NOT** place the aroma diffuser on wooden or polished furniture that may be damaged by water moisture.
2. Always unplug the aroma diffuser from the mains electrical supply when cleaning or filling with water. Always use the power adaptor supplied. Ensure the cable is secure to avoid tripping or knocking over the aroma diffuser. If the power adaptor is damaged, it must be replaced with a suitable adaptor provided by the manufacturer or its agent. Alternatively, a new adaptor can be purchased from your retailer.
3. Use a suitable measuring cup to fill the water into the water tank. Never attempt to fill water under a running tap or whilst plugged in. Do not fill the water beyond the max water level line. Carefully remove the excess water from the tank, if overfilled from the water tank from the water discharge arrow – away from the vent hole.
4. The aroma diffuser must be kept out of reach from children and pets to avoid risk of injury. Children should be supervised at all times to ensure they do not play with the appliance.
5. The aroma diffuser is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
6. Keep the aroma diffuser in a clear space to allow the mist to freely spread and away from appliances especially those sensitive to water to avoid unnecessary accidents.
7. The aroma diffuser must be cleaned after each use and should always be kept clean and dry when not in use. Never leave stagnant oil and water in the water tank for prolonged periods.
8. Never attempt to disassemble your aroma diffuser or repair the product, as this will void your warranty and create a shock hazard. Contact your retailer if an internal inspection is required.
9. In case of abnormal observations such as smoke, peculiar smells or noise, stop using the aroma diffuser immediately and contact the retailer from where you purchased it. Never wrap the adaptor with cloth or paper as blocking ventilation could increase the risk of fire.

10. Always handle the aroma diffuser with care – accidental damage is not covered under the warranty.

11. Always use water at room temperature and use only fresh, clean water from a reliable source. Do not fill the water tank with other chemicals or liquids other than water and a few drops of fragrance or essential oils.

12. Never touch the water within the water tank when the aroma diffuser is in operation as the water may become warm. It is perfectly normal for the water temperature to increase over time. Especially if it has been running for a few hours. This is caused by the energy created from the vibrating disc. The water should not exceed 40°C but for some models it can increase to 50°C (+/- 5°C). However, as the mist dissipates from the mist outlet, the water temperature cools rapidly due to the large surface area of each droplet, hence the mist is referred to as a 'cool mist'.

13. Always plug the adaptor into the DC jack before plugging into the mains.

14. Do not remove the covers during operation.


15. NEVER touch the ultrasonic ceramic disc while the diffuser is plugged in as this could cause serious injury.

16. Do not immerse the unit in water or other liquids and do not attempt to clean in a dishwasher.


17. When using the light only mode, the standby mode will not operate. Switch off the light as per the instructions in this manual.




OPERATING PROCEDURE




1. Place the diffuser on a firm and flat surface, in upright direction. Remove the cover upward carefully as shown.




2. Add water to the water tank with a suitable measuring cup until the water reaches the max. water level line as shown.




3. Add 3-5 drops of your favourite fragrance or essential oil into the water.



4. Replace the cover.



5. Plug the cable into the DC Jack before connecting the adaptor to the power source.



Note: Do not lean or move or attempt to empty or refill the diffuser during operation.

BUTTON FUNCTIONS

Light control:

- > Press the 'LAMP' button once to turn on a soft glowing white light
- > Press the 'LAMP' button again to dim the light, ideal to use a night light
- > Press the 'LAMP' button again to turn off the light.

It is possible to use aroma diffuser mist mode without the light; ideal for night time use

It is possible to use the light mode without the mist mode.

Note: when using the light only mode your aroma diffuser light will remain on until you turn off the light by pressing 'LAMP' button two times.

When operating Mist mode and Light mode together, both the mist and light will switch off automatically when the water level runs sufficiently low.


Mist control:

> Press the 'MIST' button once to turn on the aroma diffuser. The aroma diffuser will mist continuously until the water level runs low. At this point the Esta will switch off automatically (unless using light mode, see light control)


> Press the 'MIST' button to operate the intermittent mist function. The aroma diffuser will mist intermittently; 30 seconds on / 30 seconds off and will continue until the water level runs low. At this point the Esta will switch off automatically (unless using light mode, see light control)
Intermittent mist mode is ideal when using higher strength oils and/or a longer operation time is needed.

> Press the 'MIST' button again to turn off the aroma diffuser


MAINTENANCE



1. Make sure the light and mist functions have been switched off and unplug the power from the mains.




2. Remove the cover.



WARNING: DO NOT EMPTY WATER FROM THE VENT HOLE

3. Empty water via the water discharge groove.



4. Use a clean swab or cloth to clean the unit.

Caution: Always switch off the appliance and disconnect the power source from electrical outlet before cleaning.

Always keep your aroma diffuser clean and dry when not in use.

Never leave stagnant oil and water inside the tank for prolonged periods.

For stubborn oil build up, use sanitary alcohol on a cotton bud if required.

If the aroma diffuser does not generate mist (or generates little mist), clean the ceramic disc.

When cleaning, always take extra care to ensure water does not enter DC Jack power port. Allow the unit to dry thoroughly as advised below if water accidentally enters the electrical port.

Accidental Leakage: In the event of the aroma diffuser being knocked over during use, please follow the steps below to avoid malfunction.

- Unplug the diffuser from the mains and remove the cover carefully.
- Pour out any remaining water from the tank.
- Shake the diffuser gently to drain any water from inside, then leave for 24 hours for the diffuser to dry thoroughly in a well-ventilated area.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No Mist or mist volume significantly reduced	Power supply is not connected	Plug in the power adaptor and press the mist button
	Water is lower than the water level sensor	Refill the tank with ordinary tap water. Take care not to fill past the max water level line
	Water is exceeding the max water level line	Carefully pour out excess water in the direction of the water discharge arrow
	There may be a build-up of oil on the ceramic disc	Clean the ceramic disc with water and a clean cloth
	Mist outlet is blocked	Clean the mist outlet by thoroughly cleaning the inside of the cover with clean water
Unit will not switch on	There is an insufficient amount of water in the tank	Fill the water tank with water up to the max water level line. Do not over fill
	The power cable may not be connected properly	Disconnect the cable and try connecting properly
	The cover is not positioned correctly	Remove cover and replace correctly allowing mist to release correctly
Water is leaking from the product	The unit has been tipped or knocked over	Follow the accidental leakage instructions
	The temperature is low or there is high humidity	Under these conditions the mist can sometimes condense into water droplets

The intensity and amount of mist may vary, but this is not unusual and should not be considered as a fault. Factors that may affect this include water type, humidity, temperature, air currents etc.

WARRANTY

This product carries a 12-month warranty for proper use in accordance with this manual against any manufacturing defects. Accidental damage is not covered under the warranty, including glass breakage. The warranty period is 12 months from the date of purchase. In case of any problems arising during the warranty period, please contact your retailer for maintenance or claims. Proof of purchase will be required, so it is vital that you keep your receipt of purchase with this manual safely.

Corrosive oils such as Citronella may cause damage to the unit if left in the water tank. This type of damage is not covered under the warranty. This aroma diffuser must be cleaned after each use.



IMPORTANT!

madebyzen® Ultrasonic Aroma Diffusers comply with the WEEE Directive (Waste from Electrical and Electronic Equipment Directive) 2019/19/EU.

Electrical equipment is a large source of waste and if not properly recycled could have damaging effects on the environment, whereas if it is recycled, the resources could be used again.

Electronic waste needs to be separated from other waste to be recycled properly. When the Esta Aroma Diffuser reaches the end of its working life, please deposit at an appropriate collection point for recycling of electrical products. You can also recycle used electronics at Household Waste Recycling Centres.

Caring for our planet is important to us, so please help us by disposing of the Esta correctly. Thank You.