




MADE BY ZEN®



LINA

Sculpted Organic Ceramic Aroma Diffuser with soft,
ambient breathing light and remote control.

TABLE OF CONTENTS:

- A. ABOUT THE LINA
- B. TECHNICAL SPECIFICATION
- C. OPERATING INSTRUCTIONS
- D. FEATURES
- E. MAINTENANCE
- F. TROUBLESHOOTING
- G. WARRANTY

Congratulations on purchasing your MADE BY ZEN® Lina Ceramic Aroma Diffuser. Please keep this manual to help you get the most out of your Lina and for maintenance.

A - ABOUT LINA

Sculpted, serene and elegant, the Lina Ceramic Aroma Diffuser fills your space with calming mist and a soft, ambient breathing light. Inspired by the sea, Lina's organic form and soothing glow brings a sense of quiet luxury to any room. With variable mist and light settings, Lina is perfect for mindful moments, unwinding in style or whenever your space needs a gentle reset with scent and serenity. Thank you for purchasing the Lina.



Ambient Lighting

Warm ambient LED lighting with a variety of settings:

- > Breathing light, can be used to aid mindful meditation.
- > Preferred light intensity setting.
- > Sleep mode (no light) option.
- > Lamp only mode can be operated without water.



Mini Humidifier

Releases a humidifying mist.

Ideal for counteracting some of the dryness created by today's central heating and air conditioning systems.



Auto Shut Off

Safety feature (operates only when using mist function).



Adjustable Mist

Two operating modes:

- > Intermittent mist control will automatically switch the diffusion of scent and mist, on and off every few seconds, which is ideal when using stronger scents.
- > Constant Mist.

B - TECHNICAL SPECIFICATIONS

Model Name: Lina Aroma Diffuser


Model No: EWJS03-2CWM

Power: 12W

Voltage: 24

Water Capacity: 100ml

- 01. Mist Outlet
- 02. Ceramic Cover
- 03. Inner Cover
- 04. Water Tank
- 05. Air Outlet
- 06. Mist Button
- 07. Light Button
- 08. Ceramic Disc
- 09. Drainage Direction
- 10. Max. Water Level Line
- 11. Air Inlet
- 12. DC Socket
- 13. Adaptor



IMPORTANT NOTES BEFORE USE:

The Aroma Diffuser MUST be cleaned before and after each use. When stored the unit should always be kept clean and dry. NEVER leave stagnant oil and water in the water tank for any prolonged period.

Whilst using your diffuser, you MUST clean the water tank every 3 days:



Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can develop in the water reservoir, and expelled into the air when next used causing very serious health risks. To prevent this the water tank MUST be cleaned properly every 3 days.

Der Aromadiffuser MUSS vor und nach jeder Verwendung gereinigt werden. Das Gerät sollte immer in einem sauberen und trockenen Zustand gelagert werden. Lassen Sie NIE über einen längeren Zeitraum Öl und Wasser im Wassertank stehen.

Während der Verwendung Ihres Diffusers MÜSSEN Sie den Wassertank alle drei Tagen reinigen:



Eventuell im Wasser oder der Umgebung, in der das Gerät verwendet bzw. gelagert wird, vorhandene Mikroorganismen können sich im Wassertank weiterentwickeln, bei der nächsten Verwendung in die Luft austreten und somit äußerst ernsthafte Gesundheitsrisiken hervorrufen. Zur Vermeidung dessen MUSS der Wassertank alle drei Tage ordentlich gereinigt werden.

يجب تنظيف الفواحة العطرية قبل وبعد كل استعمال. في حال حفظ وتخزين الجهاز،
يجب دوماً المحافظة عليه نظيفاً وجافاً. لا تترك بقايا الزيت والماء الراتك
أبداً في خزان الماء لمدة طويلة جداً.

أثناء استعمال الفواحة العطرية، يجب عليك تنظيف خزان الماء كل ٣ أيام.





يمكن للكلاثات الدقيقة التي قد تكون موجودة في الماء أو في البيئة في حال استخدام الجهاز أو تخزينه أن تنمو في خزان الماء، ولذلك في الفواحة، وسوف يتسبب الاستعمال التالي للجهاز بأخطار صحية كبيرة جداً. لحماية خزان الماء، يجب تنظيفه على نحو مناسب كل ٣ أيام (٧٢ ساعة).


1. Place the Aroma Diffuser on a flat surface, at least 60cm away from the floor and at least 10cm away from the wall. DO NOT place the Aroma Diffuser on wooden or polished furniture that may be damaged by water moisture.
2. Always unplug the Aroma Diffuser from the electrical supply when cleaning or filling with water. Always use the power adaptor supplied. Ensure the cable is secure to avoid tripping or knocking over the Aroma Diffuser. If the power adaptor is damaged, it must be replaced with a suitable adaptor provided by the manufacturer or its agent. Alternatively, a new adaptor can be purchased from your retailer.
3. Use a suitable measuring cup to fill the water into the water tank. Never attempt to fill water under a running tap or whilst plugged in. Do not fill the water beyond the max water level line. If overfilled, carefully remove the excess water from the tank in the 'drainage direction' as shown by the arrow and away from the vent hole.
4. The Aroma Diffuser must be kept out of reach from children and pets to avoid risk of injury. Children should be supervised at all times to ensure they do not play with the appliance.
5. The Aroma Diffuser is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
6. Keep the Aroma Diffuser in a clear space to allow the mist to freely spread and away from appliances especially those sensitive to water to avoid unnecessary accidents.
7. The Aroma Diffuser must be cleaned after each use and should always be kept clean and dry when not in use. Never leave stagnant oil and water in the water tank for prolonged periods.
8. Never attempt to disassemble your Aroma Diffuser or repair the product, as this will void your warranty and create a shock hazard. Contact your retailer if an internal inspection is required.
9. In case of abnormal observations such as smoke, peculiar smells or noise, stop using the Aroma Diffuser immediately and contact the retailer from where you purchased it. Never wrap the aroma diffuser or adaptor with cloth or paper as blocking ventilation could increase the risk of fire.

10. Always handle the Aroma Diffuser with care – accidental damage is not covered under the warranty.
11. Always use water at room temperature and use only fresh, clean water from a reliable source. Do not fill the water tank with other chemicals or liquids other than water and a few drops of fragrance or essential oils.
12. Never touch the water within the water tank when the diffuser is in operation as the water may become warm. It is perfectly normal for the water temperature to increase over time. Especially if it has been running for a few hours. This is caused by the energy created from the vibrating disc. The water should not exceed 40°C but for some models it can increase to 50°C (+/- 5°C). However, as the mist dissipates from the mist outlet, the water temperature cools rapidly due to the large surface area of each droplet, hence the mist is referred to as a 'cool mist'.
13. Always plug the adaptor into the DC jack before plugging into the mains.
14. NEVER touch the ultrasonic ceramic disc while the diffuser is plugged in as this could cause serious injury.
15. Do not touch, plug or unplug the aroma diffuser with wet hands.
16. Do not immerse the unit in water or other liquids and do not attempt to clean in a dishwasher.
17. When using the light only mode, the auto shut off will not operate. Switch off the light as per the instructions below.
18. Remove the plastic insert to activate the battery before using the remote control (as shown). The battery is already included.

C - OPERATING INSTRUCTIONS



1. Place the diffuser upright on a firm and flat surface. Remove both the ceramic cover and inner cover carefully upwards as shown. You may need to hold the base firmly with your hand, before removing the covers.





2. Plug in the DC jack before connecting the adaptor to the power source.



3. Add tap water to the water reservoir using a suitable filling cup, to the max level line.

4. Add 3-5 drops of your favourite fragrance or essential oil into the water.



5. Replace both the inner and ceramic covers. To switch on the unit, please see button functions below.

Note: Do not lean or move or attempt to empty or refill the diffuser during operation.

BUTTON FUNCTIONS


MIST CONTROL

- > **Press MIST once** to operate the mist function. The Aroma Diffuser will mist continuously until the water level runs low. At this point the Lina will switch off automatically.
- > **Press MIST twice** to operate intermittent mist function. The aroma diffuser will mist intermittently (30 seconds on / 30 seconds off) until the water level runs low. At this point, the Lina will switch off automatically.
- > **Press MIST three times** to turn off the mist function

LIGHT CONTROL

- > **Press LIGHT button once:** An ambient breathing light will activate. The light will gradually fade from bright to dim and gradually increase from dim to bright.
- > **Press LIGHT twice** to freeze light intensity
- > **Press LIGHT three times** to turn off the light mode.

REMOTE CONTROL



On/Off Button

Switch on the Lina, using the On/Off button on the remote control panel
>Press once to switch on unit, the breathing ambient light will switch on.
>Press twice to switch off the unit.

Light Button

After Lina has been switched on via the power button, The mist and light buttons will activate only after switching on the unit using the On/Off button.

>Press once to freeze light intensity.

>Press twice to switch off light (mist will stay on if activated).

MIST Button

After Lina has been switched on via the power button,

> Press once or constant mist.

>Press twice to switch off mist (light will stay on if activated).

INTERMITTENT MIST Button

After Lina has been switched on via the power button,

> Press once for intermittent mist (30 seconds on / 30 seconds off)


>Press two times to switch off mist (light will stay on if activated).

D - FEATURES


The Lina Ultrasonic Ceramic Aroma Diffuser provides a revolutionary way to fragrance your surroundings. It works by creating high frequency vibrations that breaks down the water and oil into minute particles which are then effectively diffused into the immediate surroundings.

- Unique patented design.
- Low energy LED lights.
- Mini humidifier.
- Aroma Diffuser: Can be used with ambient lighting or without the light, ideal for night time use.
- Night Lamp: Can be used without the mist, ideal as a night light.
- Decorative Lamp: can be used independently with and without the mist function.
- Quiet operation.
- Auto-shut off when water runs out for an additional safety.
- Easy to clean and use.


E - MAINTENANCE




1. Make sure the unit has been switched off and unplug the power from the mains.



2. Remove the ceramic cover and inner cover upward carefully as shown.



3. Empty water via the water drainage side, as shown by the arrow at the base of the water tank.



4. Use a clean swab or cloth to clean the unit.

Caution: Always switch off the unit and disconnect the cable from the power source before cleaning.

Always keep your Aroma Diffuser clean and dry when not in use.

Never leave stagnant oil and water inside the tank for prolonged periods.

If the aroma diffuser stops generating mist (or generates little mist), clean the ceramic disc as indicated above. For stubborn oil build up, use sanitary alcohol on a cotton bud if required.

For stubborn oil build up, use sanitary alcohol on a cotton bud if required.

If the Aroma Diffuser does not generate mist (or generates little mist), clean the ceramic disc.

When cleaning, always take extra care to ensure water does not enter DC jack power port. Allow the unit to dry thoroughly as advised below if water accidentally enters the electrical port.

Accidental Leakage: In the event of the aroma diffuser being knocked over during use, please follow the steps below to avoid malfunction.

- Unplug the diffuser from the mains and remove the cover carefully.
- Pour out any remaining water from the tank.
- Shake the diffuser gently to drain any water from inside, then leave for 24 hours for the diffuser to dry thoroughly in a well-ventilated area.

F - TROUBLESHOOTING

Problem	Possible Cause	Solution
No Mist or mist volume significantly reduced	Power supply is not connected.	Plug in the power adaptor and press the mist button on the base.
	Water is lower than the water level sensor.	Refill the tank with ordinary tap water. Take care not to fill past the max water level line.
	Water is exceeding the max water level line.	Carefully pour out excess water via the water drain side.
	There may be a build-up of oil on the ceramic disc.	Clean the ceramic disc with water and a clean cloth.
	Mist outlet is blocked.	Clean the mist outlet by thoroughly cleaning the inside of the cover with clean water. Ensure the ceramic cover is aligned correctly and not blocking the mist.
Unit will not switch on	There is insufficient water in the reservoir.	Carefully fill the reservoir with water to the max water level line. Do not overfill.
	The power cable may not be connected properly.	Disconnect the cable and try connecting properly.
Water is leaking from the product	The covers are not positioned correctly.	Remove the covers and replace correctly allowing mist to release correctly.
	The unit has been tipped or knocked over.	Follow the accidental leakage instructions.
	The temperature is low or there is high humidity.	Under these conditions the mist can sometimes condense into water droplets.
Remote Control not working	The battery may have stopped working.	Please unscrew the battery section on back of the remote and change the battery (screwdriver not included).

The intensity and amount of mist may vary, but this is not unusual and should not be considered as a fault. Factors that may affect this include water type, humidity, temperature, air currents etc.

G - WARRANTY

This product carries a 12-month warranty for proper use in accordance with this manual against any manufacturing defects. Accidental damage is not covered under the warranty.

The warranty period is 12 months from the date of purchase. In case of any problems arising during the warranty period, please contact your retailer for maintenance or claims. Proof of purchase will be required, so it is vital that you keep your receipt of purchase with this safety manual.

Corrosive oils such as Citronella may cause damage to the unit if left in the water tank. This type of damage is not covered under the warranty. This Aroma Diffuser must be cleaned after each use.



IMPORTANT!

MADE BY ZEN® Ultrasonic Aroma Diffusers comply with the WEEE Directive (Waste from Electrical and Electronic Equipment Directive) 2012/19/EU.

When the Lina Aroma Diffuser reaches the end of its working life, it should not be disposed of in the normal waste stream, but at an appropriate collection point for the recycling of electrical products.

Caring for our planet is important to us, so please help us by disposing of Lina correctly. Thank you.



MADE BY ZEN®

MADEBYZEN.COM